



## RT Box LaunchPad Interface

**User Manual** June 2022



### How to Contact Plexim:

☎	+41 44 533 51 00	Phone
	+41 44 533 51 01	Fax
✉	Plexim GmbH Technoparkstrasse 1 8005 Zurich Switzerland	Mail
@	info@plexim.com	Email
	<a href="http://www.plexim.com">http://www.plexim.com</a>	Web

*RT Box LaunchPad Interface*

© 2022 by Plexim GmbH

PLECS is a registered trademark of Plexim GmbH. Other product or brand names are trademarks or registered trademarks of their respective holders.

# Contents

<b>Contents</b>	<b>iii</b>
<b>1 Introduction</b>	<b>1</b>
<b>2 Interface Board Overview</b>	<b>3</b>
LaunchPad Headers . . . . .	6
Onboard Voltage Supply . . . . .	6
Analog Output . . . . .	7
Digital I/O . . . . .	8
Connectors . . . . .	8
<b>3 Appendix</b>	<b>11</b>
LAUNCHXL-F28069M Pin Map . . . . .	12
LAUNCHXL-F28377S Pin Map . . . . .	15
LAUNCHXL-F28379D Pin Map . . . . .	18
LAUNCHXL-F28027 Pin Map . . . . .	21
LAUNCHXL-F280049C Pin Map . . . . .	23
LAUNCHXL-F280039C Pin Map . . . . .	26



# Introduction

The PLECS RT Box 1 is a powerful real-time simulator based on a 1 GHz Xilinx Zynq system on a chip (SOC). With its 64 digital and 32 analog I/O signals, the RT Box is well equipped for hardware-in-the-loop (HIL) testing as well as rapid control prototyping.

If employed for HIL testing the RT Box typically emulates the power stage of a power electronic system. The power stage could be a simple DC/DC converter, an AC drive system or a complex multi-level inverter system. The device under test (DUT) is the control hardware connected to the RT Box. In such a setup, the complete controller can be tested without the real power stage.

To simplify the connection of external hardware and to provide convenient access to the RT Box inputs and outputs, Plexim offers a set of RT Box accessories.

The **RT Box LaunchPad Interface** described in this document facilitates a simple connection of the RT Box with the LaunchPad and LaunchPad XL development kits from Texas Instruments. It enables the user to test control algorithms implemented on C2000 MCUs without developing their own interface hardware. The pinout of the LaunchPad Interface board has been optimized for the following development kits:


- LaunchXL-F28069M
- LaunchXL-F28377S
- LaunchXL-F28379D
- LaunchXL-F28027

The LaunchPad Interface may also be used with other development boards compliant with the LaunchPad pinout.



# Interface Board Overview


The LaunchPad Interface board facilitates the connection between a LaunchPad from TI with a C2000 microcontroller and the RT Box. Fig. 2.1 shows the top view of the board without any LaunchPad attached.



**Figure 2.1: Top view of RT Box LaunchPad Interface**

Additionally, the board provides access to some of the analog outputs of the RT Box via BNC connectors and to unused digital inputs and outputs signals via shrouded pin headers. For simple status communication with the RT Box the board features four sliding switches and four LEDs.


Fig. 2.2 shows the top view of the board with a LaunchXL-F28069M attached.



**Figure 2.2: RT Box LaunchPad Interface with LaunchXL-F28069M**



Fig. 2.3 shows the top view of the board with a LaunchXL-F28027 attached.



**Figure 2.3: RT Box LaunchPad Interface with LaunchXL-F28027**

## LaunchPad Headers

A LaunchPad must be attached to the Interface board using the corresponding pin headers. The LaunchPad will extend beyond the edge of the Interface board. Fig. 2.2 and 2.3 show the correct mounting position.

Tables 2.1 and 2.2 list the pin assignments of the LaunchPad headers and the RT Box signals.

RT Box	Header		RT Box
	<b>J1</b>	<b>J3</b>	
3.3 V	<b>1</b>	<b>21</b>	
	<b>2</b>	<b>22</b>	GND
DO0	<b>3</b>	<b>23</b>	AO0
DO1	<b>4</b>	<b>24</b>	AO1
DO2	<b>5</b>	<b>25</b>	AO2
	<b>6</b>	<b>26</b>	AO3
DI24	<b>7</b>	<b>27</b>	AO4
DI25	<b>8</b>	<b>28</b>	AO5
DI26	<b>9</b>	<b>29</b>	AO6
DO27	<b>10</b>	<b>30</b>	AO7

RT Box	Header		RT Box
	<b>J4</b>	<b>J2</b>	
DI0	<b>40</b>	<b>20</b>	GND
DI1	<b>39</b>	<b>19</b>	DI6
DI2	<b>38</b>	<b>18</b>	DI7
DI3	<b>37</b>	<b>17</b>	
DI4	<b>36</b>	<b>16</b>	DO25
DI5	<b>35</b>	<b>15</b>	DI27
DO4	<b>34</b>	<b>14</b>	DO26
DO5	<b>33</b>	<b>13</b>	DO6
	<b>32</b>	<b>12</b>	DO7
	<b>31</b>	<b>11</b>	DO3

**Table 2.1: LaunchPad header pins J1-J4**

A more detailed table including the available processor functions at each pin for the supported LaunchPads can be found in the appendix.

## Onboard Voltage Supply

As the LaunchPad is powered from the interface board no external power supply is required. The interface board contains a linear voltage regulator that converts the 5 V supplied by the RT Box down to 3.3 V required by the LaunchPad.

RT Box	Header		RT Box	RT Box	Header		RT Box	
	<b>J5</b>	<b>J7</b>			<b>J8</b>	<b>J6</b>		
3.3 V	<b>41</b>	<b>61</b>			DI16	<b>80</b>	<b>60</b>	GND
	<b>42</b>	<b>62</b>	GND		DI17	<b>79</b>	<b>59</b>	DI22
DO16	<b>43</b>	<b>63</b>	AO8		DI18	<b>78</b>	<b>58</b>	DI23
DO17	<b>44</b>	<b>64</b>	AO9		DI19	<b>77</b>	<b>57</b>	
DO18	<b>45</b>	<b>65</b>	AO10		DI20	<b>76</b>	<b>56</b>	
	<b>46</b>	<b>66</b>	AO11		DI21	<b>75</b>	<b>55</b>	DO20
	<b>47</b>	<b>67</b>	AO12			<b>74</b>	<b>54</b>	DO21
DO19	<b>48</b>	<b>68</b>	AO13			<b>73</b>	<b>53</b>	DO22
	<b>49</b>	<b>69</b>	AO14			<b>72</b>	<b>52</b>	DO23
	<b>50</b>	<b>70</b>	AO15			<b>71</b>	<b>51</b>	DO24

**Table 2.2: LaunchPad header pins J5-J8**

The pins labeled  $5\text{ V}$  at pin headers  $J1$  and  $J5$  of the interface board are supplied with  $5\text{ V}$  generated by the TI launchpad. Therefore, a  $5\text{ V}$  output at these pins is only available when a TI launchpad is present.

Both supply voltages  $5\text{ V}$  and  $3.3\text{ V}$  are accessible at a 3-pin header on the interface board if the user wants to power external circuits. The maximum load for both voltage levels combined is  $1.5\text{ A}$ . When an external circuit requires a  $5\text{ V}$  supply it is recommended to draw the required power from the 3-pin header on the interface board and not from the LaunchPad in order to minimize losses and component stress.

## Analog Output

The interface board connects all 16 analog outputs from the RT Box to the LaunchPad headers. The lower 8 channels  $AO0\dots AO7$  are also accessible at the BNC connectors. Each of the analog output channels is clamped with two Schottky diodes to  $0\text{ V}$  and  $3.3\text{ V}$  to protect the inputs of the MCU from damage by overvoltage.

To stabilize the analog voltages for the sample and hold capacitors inside the MCU, each channel is buffered with a 220 pF capacitor against ground.

## Digital I/O

Not all of the digital inputs and outputs of the RT Box are connected to the LaunchPad. The unused digital inputs *DI8...DI15* and the outputs *DO8...DO15* are freely accessible at the shrouded headers on the lower side of interface board. The digital outputs *DO28...DO31* are connected to four orange LEDs in the lower right corner of the board. The digital inputs *DI28...DI31* can be set via four sliding switches.

All other digital inputs and outputs from the RT Box are connected to the LaunchPad headers. To protect the inputs of the MCU from voltages greater than 3.3V, the corresponding outputs of the RT Box are buffered with bus transceivers.

DO25 is connected to the MCU reset pin via the *RST* jumper. If the jumper is set a low-level output at DO25 will reset the MCU. Do not set this jumper unless you wish to use this feature.

## Connectors

The following table contains the part numbers of the connectors and standoff assembly used on the LaunchPad interface board. For dimensions of the front panel of the RT Box, refer to the RT Box manual.

<b>Sl. No.</b>	<b>Manufacturer</b>	<b>Part Number</b>	<b>Description</b>
1	Sullins Connector Solutions	PRPC010DAAN-RC	20-pin Header
2	On Shore Technology Inc.	302-S161	16-pin Header
3	3M	961103-5604-AR	3-pin Header
4	3M	961102-6404-AR	2-pin Header
5	Radiall	R141426161	BNC Connector
6	Assmann WSW Components	A-DS 37 A/KG-T4S	37-pin D-Sub Male
7	Assmann WSW Components	ASUB-277-37TP25	37-pin D-Sub Stacked
8	Harwin Inc.	R6396-02	Hex Standoff
9	Keystone Electronics	720	Bumper
10	APM Hexseal	RM3X8MM 2701	M3 Screw

**Table 2.3: Connectors and standoff assembly**



# Appendix

The tables on the next pages provide more detailed information on the connectivity of the LaunchPad Interface. For each LaunchPad, the RT Box I/O is shown beside the header pins and the processor peripherals available at those pins. Note that only peripherals are listed which are compliant with the type and direction of the RT Box I/O.

## LAUNCHXL-F28069M Pin Map

Function	RT Box			RT Box	Function
		<b>J1</b>	<b>J3</b>		
	3.3V	<b>1</b>	<b>21</b>		
		<b>2</b>	<b>22</b>	GND	
J1.3	DO0	<b>3</b>	<b>23</b>	AO0	ADCINA7
J1.4	DO1	<b>4</b>	<b>24</b>	AO1	ADCINB1
GPIO12, TZ1	DO2	<b>5</b>	<b>25</b>	AO2	ADCINA2
		<b>6</b>	<b>26</b>	AO3	ADCINB2
GPIO18, SPICLKA	DI24	<b>7</b>	<b>27</b>	AO4	ADCINA0
GPIO22, EQEP1S	DI25	<b>8</b>	<b>28</b>	AO5	ADCINB0
GPIO33, EPWMSYNCO, ADCSOCBO	DI26	<b>9</b>	<b>29</b>	AO6	ADCINA1
GPIO32, EPWMSYNCI	DO27	<b>10</b>	<b>30</b>	AO7	NC
		<b>J5</b>	<b>J7</b>		
	3.3V	<b>41</b>	<b>61</b>		
		<b>42</b>	<b>62</b>	GND	
J7.3	DO16	<b>43</b>	<b>63</b>	AO8	ADCINB7
J7.4	DO17	<b>44</b>	<b>64</b>	AO9	ADCINB4
GPIO20, EQEP1A	DO18	<b>45</b>	<b>65</b>	AO10	ADCINA5
		<b>46</b>	<b>66</b>	AO11	ADCINB5
		<b>47</b>	<b>67</b>	AO12	ADCINA3
GPIO21, EQEP1B	DO19	<b>48</b>	<b>68</b>	AO13	ADCINB3
		<b>49</b>	<b>69</b>	AO14	ADCINA4
		<b>50</b>	<b>70</b>	AO15	NC



Function	RT Box			RT Box	Function
----------	--------	--	--	--------	----------

**Table 3.1: LAUNCHXL-F28069M pin map for J1, J3, J5 and J7**

Function	RT Box			RT Box	Function
		<b>J4</b>	<b>J2</b>		
GPIO0, EPWM1A	DI0	<b>40</b>	<b>20</b>	GND	
GPIO1, EPWM1B	DI1	<b>39</b>	<b>19</b>	DI6	GPIO19, SPISTEA
GPIO2, EPWM2A	DI2	<b>38</b>	<b>18</b>	DI7	GPIO44, EPWM7B
GPIO3, EPWM2B	DI3	<b>37</b>	<b>17</b>		
GPIO4, EPWM3A	DI4	<b>36</b>	<b>16</b>	DO25	<b>RESET</b>
GPIO5, EPWM3B, SPISIMOA	DI5	<b>35</b>	<b>15</b>	DI27	GPIO16, SPISIMOA
GPIO13, TZ2, SPISOMIB	DO4	<b>34</b>	<b>14</b>	DO26	GPIO17, SPISOMIA, TZ3
NC	DO5	<b>33</b>	<b>13</b>	DO6	GPIO50, EQEP1A, TZ1
		<b>32</b>	<b>12</b>	DO7	GPIO51, EQEP1B, TZ2
		<b>31</b>	<b>11</b>	DO3	GPIO55, SPISOMIA, EQEP2B
		<b>J8</b>	<b>J6</b>		
GPIO6, EPWM4A, EPWM-SYNCO	DI16	<b>80</b>	<b>60</b>	GND	
GPIO7, EPWM4B	DI17	<b>79</b>	<b>59</b>	DI22	GPIO27, SPISTEB
GPIO8, EPWM5A, ADCSO-CAO	DI18	<b>78</b>	<b>58</b>	DI23	GPIO26, SPICLKB
GPIO9, EPWM5B	DI19	<b>77</b>	<b>57</b>		
GPIO10, EPWM6A, ADC-SOCBO	DI20	<b>76</b>	<b>56</b>		
GPIO11, EPWM6B	DI21	<b>75</b>	<b>55</b>	DO20	GPIO24, EQEP2A

<b>Function</b>	<b>RT Box</b>			<b>RT Box</b>	<b>Function</b>
		<b>74</b>	<b>54</b>	DO21	GPIO25, EQEP2B
		<b>73</b>	<b>53</b>	DO22	GPIO52, EQEP1S, TZ3
		<b>72</b>	<b>52</b>	DO23	GPIO53, EQEP1I
		<b>71</b>	<b>51</b>	DO24	GPIO56, EQEP2I

**Table 3.2: LAUNCHXL-F28069M pin map for J2, J4, J6 and J8**

## LAUNCHXL-F28377S Pin Map

Function	RT Box			RT Box	Function
		<b>J1</b>	<b>J3</b>		
	3.3V	<b>1</b>	<b>21</b>		
		<b>2</b>	<b>22</b>	GND	
GPIO90	DO0	<b>3</b>	<b>23</b>	AO0	ADCIN14
GPIO89	DO1	<b>4</b>	<b>24</b>	AO1	ADCINB1
GPIO41	DO2	<b>5</b>	<b>25</b>	AO2	ADCINB4
		<b>6</b>	<b>26</b>	AO3	ADCINB2
GPIO60, SPICLKA, OUT-XBAR3	DI24	<b>7</b>	<b>27</b>	AO4	ADCINA0
GPIO61, SPISTEA, OUT-XBAR4	DI25	<b>8</b>	<b>28</b>	AO5	ADCINB0
GPIO43	DI26	<b>9</b>	<b>29</b>	AO6	ADCINA1
NC	DO27	<b>10</b>	<b>30</b>	AO7	NC
		<b>J5</b>	<b>J7</b>		
	3.3V	<b>41</b>	<b>61</b>		
		<b>42</b>	<b>62</b>	GND	
GPIO87	DO16	<b>43</b>	<b>63</b>	AO8	ADCIN15
GPIO86	DO17	<b>44</b>	<b>64</b>	AO9	ADCINA2
NC	DO18	<b>45</b>	<b>65</b>	AO10	ADCINA5
		<b>46</b>	<b>66</b>	AO11	ADCINB5
		<b>47</b>	<b>67</b>	AO12	ADCINA3
NC	DO19	<b>48</b>	<b>68</b>	AO13	ADCINB3
		<b>49</b>	<b>69</b>	AO14	ADCINA4

Function	RT Box			RT Box	Function
		<b>50</b>	<b>70</b>	AO15	NC

**Table 3.3: LAUNCHXL-F28377 pin map for J1, J3, J5 and J7**

Function	RT Box			RT Box	Function
		<b>J4</b>	<b>J2</b>		
GPIO12, EPWM7A	DI0	<b>40</b>	<b>20</b>	GND	
GPIO13, EPWM7B	DI1	<b>39</b>	<b>19</b>	DI6	GPIO4, EPWM3A, OUT-XBAR3
GPIO14, EPWM8A, OUT-XBAR3	DI2	<b>38</b>	<b>18</b>	DI7	GPIO62
GPIO15, EPWM8B, OUT-XBAR4	DI3	<b>37</b>	<b>17</b>		
GPIO16, EPWM9A, SPISIMOA, OUTXBAR7	DI4	<b>36</b>	<b>16</b>	DO25	<b>RESET</b>
GPIO17, EPWM9B, OUT-XBAR8	DI5	<b>35</b>	<b>15</b>	DI27	GPIO58, SPICLKB, OUT-XBAR1, SPISIMOA
GPIO20, EQEP1A, SD1_D3	DO4	<b>34</b>	<b>14</b>	DO26	GPIO59, SD2_C2, SPISOMIA
GPIO21, EQEP1B, SD1_C3	DO5	<b>33</b>	<b>13</b>	DO6	GPIO72
		<b>32</b>	<b>12</b>	DO7	GPIO73
		<b>31</b>	<b>11</b>	DO3	GPIO78, EQEP2A
		<b>J8</b>	<b>J6</b>		
GPIO2, EPWM2A, OUT-XBAR1	DI16	<b>80</b>	<b>60</b>	GND	
GPIO3, EPWM2B, OUT-XBAR2	DI17	<b>79</b>	<b>59</b>	DI22	GPIO91
GPIO10, EPWM6A	DI18	<b>78</b>	<b>58</b>	DI23	NC

<b>Function</b>	<b>RT Box</b>			<b>RT Box</b>	<b>Function</b>
GPIO11, EPWM6B, OUT-XBAR7	DI19	<b>77</b>	<b>57</b>		
GPIO18, SPICLKA, EPWM10A	DI20	<b>76</b>	<b>56</b>		
GPIO19, SPISTEA, EPWM10B	DI21	<b>75</b>	<b>55</b>	DO20	GPIO63, EQEP3B, SD2_C4
		<b>74</b>	<b>54</b>	DO21	GPIO64, EQEP3S, SPISOMIB
		<b>73</b>	<b>53</b>	DO22	GPIO99, EQEP1I
		<b>72</b>	<b>52</b>	DO23	GPIO92
		<b>71</b>	<b>51</b>	DO24	NC

**Table 3.4: LAUNCHXL-F28377 pin map for J2, J4, J6 and J8**

## LAUNCHXL-F28379D Pin Map

Function	RT Box			RT Box	Function
		<b>J1</b>	<b>J3</b>		
	3.3V	<b>1</b>	<b>21</b>		
		<b>2</b>	<b>22</b>	GND	
GPIO19, SD1_C2	DO0	<b>3</b>	<b>23</b>	AO0	ADCINA14, CMPIN4P
GPIO18, SD1_D2	DO1	<b>4</b>	<b>24</b>	AO1	ADCINC3, CMPIN6N
GPIO67	DO2	<b>5</b>	<b>25</b>	AO2	ADCINB3, CMPIN3N
		<b>6</b>	<b>26</b>	AO3	ADCINA3, CMPIN1N
GPIO60, SPICLKA, OUT-XBAR3, SPISIMOB	DI24	<b>7</b>	<b>27</b>	AO4	ADCINC2, CMPIN6P
GPIO22, EPWM12A, SPI-CLKB	DI25	<b>8</b>	<b>28</b>	AO5	ADCINB2, CMPIN3P
GPIO105	DI26	<b>9</b>	<b>29</b>	AO6	ADCINA2, CMPIN1P
GPIO104, EQEP3A	DO27	<b>10</b>	<b>30</b>	AO7	ADCINA0
		<b>J5</b>	<b>J7</b>		
	3.3V	<b>41</b>	<b>61</b>		
		<b>42</b>	<b>62</b>	GND	
GPIO139	DO16	<b>43</b>	<b>63</b>	AO8	ADCIN15, CMPIN4N
GPIO56, EQEP2S, SD2_D1	DO17	<b>44</b>	<b>64</b>	AO9	ADCINC5, CMPIN5N
GPIO97, EQEP1B	DO18	<b>45</b>	<b>65</b>	AO10	ADCINB5
		<b>46</b>	<b>66</b>	AO11	ADCINA5, CMPIN2N
		<b>47</b>	<b>67</b>	AO12	ADCINC4, CMPIN5P
GPIO52, EQEP1S, SD1_D3	DO19	<b>48</b>	<b>68</b>	AO13	ADCINB4
		<b>49</b>	<b>69</b>	AO14	ADCINA4, CMPIN2P

Function	RT Box			RT Box	Function
		<b>50</b>	<b>70</b>	AO15	ADCINA1

**Table 3.5: LAUNCHXL-F28379D pin map for J1, J3, J5 and J7**

Function	RT Box			RT Box	Function
		<b>J4</b>	<b>J2</b>		
GPIO0, EPWM1A	DI0	<b>40</b>	<b>20</b>	GND	
GPIO1, EPWM1B	DI1	<b>39</b>	<b>19</b>	DI6	GPIO61, SPISTEAA, OUTXBAR4
GPIO2, EPWM2A, OUTXBAR1	DI2	<b>38</b>	<b>18</b>	DI7	GPIO123
GPIO3, EPWM2B, OUTXBAR2	DI3	<b>37</b>	<b>17</b>		
GPIO4, EPWM3A, OUTXBAR3	DI4	<b>36</b>	<b>16</b>	DO25	<b>RESET</b>
GPIO5, EPWM3B, OUTXBAR3	DI5	<b>35</b>	<b>15</b>	DI27	GPIO58, SPICLKB, SPISIMOA, OUTXBAR1
GPIO24, EQEP2A, SD2_D1	DO4	<b>34</b>	<b>14</b>	DO26	GPIO59, SPISOMIA, SD2_C2
GPIO16, SD1_D1	DO5	<b>33</b>	<b>13</b>	DO6	GPIO124, SD1_D2
		<b>32</b>	<b>12</b>	DO7	GPIO125, SD1_C2
		<b>31</b>	<b>11</b>	DO3	GPIO29, EQEP3B, SD2_C3
		<b>J8</b>	<b>J6</b>		
GPIO6, EPWM4A, OUTXBAR4	DI16	<b>80</b>	<b>60</b>	GND	
GPIO7, EPWM4B, OUTXBAR5	DI17	<b>79</b>	<b>59</b>	DI22	GPIO66, SPISTEB

<b>Function</b>	<b>RT Box</b>			<b>RT Box</b>	<b>Function</b>
GPIO8, EPWM5A, ADCSO-CAO	DI18	<b>78</b>	<b>58</b>	DI23	GPIO131
GPIO9, EPWM5B, OUT-XBAR6	DI19	<b>77</b>	<b>57</b>		
GPIO10, EPWM6A, ADC-SOCBO	DI20	<b>76</b>	<b>56</b>		
GPIO11, EPWM6B, OUT-XBAR 7	DI21	<b>75</b>	<b>55</b>	DO20	GPIO63, EQEP3B, SD2_C4
		<b>74</b>	<b>54</b>	DO21	GPIO64, EQEP3S, SPISOMIB
		<b>73</b>	<b>53</b>	DO22	GPIO26, EQEP2I, SD2_D2
		<b>72</b>	<b>52</b>	DO23	GPIO27, EQEP2S, SD2_C2
		<b>71</b>	<b>51</b>	DO24	GPIO25, EQEP2B, SPI-SOMIB, SD2_C1

**Table 3.6: LAUNCHXL-F28379D pin map for J2, J4, J6 and J8**



## LAUNCHXL-F28027 Pin Map

Function	RT Box			RT Box	Function
		<b>J4/J6</b>	<b>J2/J2</b>		
GPIO0, EPWM1A	DI0	<b>40/1</b>	<b>20/1</b>	GND	
GPIO1, EPWM1B	DI1	<b>39/2</b>	<b>19/2</b>	DI6	GPIO19, SPISTEA
GPIO2, EPWM2A	DI2	<b>38/3</b>	<b>18/3</b>	DI7	GPIO12
GPIO3, EPWM2B	DI3	<b>37/4</b>	<b>17/4</b>		
GPIO4, EPWM3A	DI4	<b>36/5</b>	<b>16/5</b>	DO25	<b>RESET</b>
GPIO5, EPWM3B	DI5	<b>35/6</b>	<b>15/6</b>	DI27	GPIO16/32, SPISIMOA(16), ADCSOCA(32)
GPIO16/32, EPWM-SYNCCI(32), TZ2(16)	DO4	<b>34/7</b>	<b>14/7</b>	DO26	GPIO17/33, SPISOMIA(17), TZ3(17)
GPIO17/33, SPISOMIA(17), TZ3(17)	DO5	<b>33/8</b>	<b>13/8</b>	DO6	GPIO6, EPWMSYNCCI
		<b>32/9</b>	<b>12/9</b>	DO7	GPIO7
		<b>31/10</b>	<b>11/10</b>	DO3	NC
		<b>J1</b>	<b>J3/J5</b>		
	3.3V	<b>1</b>	<b>21/1</b>		
		<b>2</b>	<b>22/2</b>	GND	
GPIO28, TZ2	DO0	<b>3</b>	<b>23/3</b>	AO0	ADCINA7
GPIO29, TZ3	DO1	<b>4</b>	<b>24/4</b>	AO1	ADCINA3
GPIO34	DO2	<b>5</b>	<b>25/5</b>	AO2	ADCINA1
		<b>6</b>	<b>26/6</b>	AO3	ADCINA0
GPIO18, SPICLK	DI24	<b>7</b>	<b>27/7</b>	AO4	ADCINB1
	DI25	<b>8</b>	<b>28/8</b>	AO5	ADCINB3
	DI26	<b>9</b>	<b>29/9</b>	AO6	ADCINB7

---

	DO27	<b>10</b>	<b>30/10</b>	AO7	NC
--	------	-----------	--------------	-----	----

---

**Table 3.7: LAUNCHXL-F28027 pin map**

## LAUNCHXL-F280049C Pin Map

Function	RT Box			RT Box	Function
		<b>J1</b>	<b>J3</b>		
	3.3V	<b>1</b>	<b>21</b>		
		<b>2</b>	<b>22</b>	GND	
GPIO13	DO0	<b>3</b>	<b>23</b>	AO0	ADCINA5
GPIO40	DO1	<b>4</b>	<b>24</b>	AO1	ADCINB0
	DO2	<b>5</b>	<b>25</b>	AO2	ADCINC2
		<b>6</b>	<b>26</b>	AO3	ADCINB1
GPIO56, SPICLKA	DI24	<b>7</b>	<b>27</b>	AO4	ADCINB2
ADCINC4	DI25	<b>8</b>	<b>28</b>	AO5	ADCINC0
GPIO37, EQEP1B	DI26	<b>9</b>	<b>29</b>	AO6	ADCINA9
GPIO35, EQEP1A	DO27	<b>10</b>	<b>30</b>	AO7	ADCINA1
		<b>J5</b>	<b>J7</b>		
	3.3V	<b>41</b>	<b>61</b>		
		<b>42</b>	<b>62</b>	GND	
GPIO28, EQEP1A	DO16	<b>43</b>	<b>63</b>	AO8	ADCINA6
GPIO29, EQEP1B	DO17	<b>44</b>	<b>64</b>	AO9	ADCINB6
ADCINB4	DO18	<b>45</b>	<b>65</b>	AO10	ADCINC14
		<b>46</b>	<b>66</b>	AO11	ADCINC1
		<b>47</b>	<b>67</b>	AO12	ADCINC3
ADCINA8	DO19	<b>48</b>	<b>68</b>	AO13	ADCINC5
		<b>49</b>	<b>69</b>	AO14	ADCINA3
		<b>50</b>	<b>70</b>	AO15	ADCINA0

**Table 3.8: LAUNCHXL-F280049C pin map for J1, J3, J5 and J7**

Function	RT Box			RT Box	Function
		<b>J4</b>	<b>J2</b>		
GPIO10, EPWM6A, EQEP1A	DI0	<b>40</b>	<b>20</b>	GND	
GPIO11, EPWM6B, EQEP1B	DI1	<b>39</b>	<b>19</b>	DI6	GPIO57, SPISTEA
GPIO8, EPWM5A	DI2	<b>38</b>	<b>18</b>	DI7	
GPIO9, EPWM5B, EQEP1I, OUTXBAR6	DI3	<b>37</b>	<b>17</b>		
GPIO4, EPWM3A	DI4	<b>36</b>	<b>16</b>	DO25	<b>RESET</b>
GPIO5, EPWM3B, OUT- XBAR3	DI5	<b>35</b>	<b>15</b>	DI27	GPIO16, SPISIMOA
GPIO58, OUTXBAR1	DO4	<b>34</b>	<b>14</b>	DO26	GPIO17, SPISOMIA
GPIO30, OUTXBAR7	DO5	<b>33</b>	<b>13</b>	DO6	GPIO39
		<b>32</b>	<b>12</b>	DO7	GPIO23
		<b>31</b>	<b>11</b>	DO3	GPIO59, EQEP1I
		<b>J8</b>	<b>J6</b>		
GPIO0, EPWM1A	DI16	<b>80</b>	<b>60</b>	GND	
GPIO1, EPWM1B	DI17	<b>79</b>	<b>59</b>	DI22	GPIO27, SPISTEB
GPIO6, EPWM4A	DI18	<b>78</b>	<b>58</b>	DI23	
GPIO7, EPWM4B, OUT- XBAR5	DI19	<b>77</b>	<b>57</b>		
GPIO2, EPWM2A	DI20	<b>76</b>	<b>56</b>		
GPIO3, EPWM2B, OUT- XBAR2	DI21	<b>75</b>	<b>55</b>	DO20	GPIO24, SPISIMOB
		<b>74</b>	<b>54</b>	DO21	GPIO31, SPISOMIB

<b>Function</b>	<b>RT Box</b>			<b>RT Box</b>	<b>Function</b>
		<b>73</b>	<b>53</b>	DO22	GPIO33, SPISTEB
		<b>72</b>	<b>52</b>	DO23	GPIO34
		<b>71</b>	<b>51</b>	DO24	GPIO12

**Table 3.9: LAUNCHXL-F280049C pin map for J2, J4, J6 and J8**

## LAUNCHXL-F280039C Pin Map

Function	RT Box			RT Box	Function
		<b>J1</b>	<b>J3</b>		
	3.3V	<b>1</b>	<b>21</b>		
		<b>2</b>	<b>22</b>	GND	
GPIO28, SCIA_RX	DO0	<b>3</b>	<b>23</b>	AO0	ADCINA6
GPIO29, SCIA_TX	DO1	<b>4</b>	<b>24</b>	AO1	ADCINA2/B6/C9
	DO2	<b>5</b>	<b>25</b>	AO2	ADCINA3/B9/C7
		<b>6</b>	<b>26</b>	AO3	ADCINA14/B14/C4
GPIO9, SPIA_CLK	DI24	<b>7</b>	<b>27</b>	AO4	ADCINA11/B10/C0
GPIO24, BOOT1	DI25	<b>8</b>	<b>28</b>	AO5	ADCINB12/C2
GPIO51, I2CB_SCL	DI26	<b>9</b>	<b>29</b>	AO6	ADCINA7/C3
GPIO34, I2CB_SDA	DO27	<b>10</b>	<b>30</b>	AO7	ADCINA1/B7
		<b>J5</b>	<b>J7</b>		
	3.3V	<b>41</b>	<b>61</b>		
		<b>42</b>	<b>62</b>	GND	
GPIO15, SCIB_RX	DO16	<b>43</b>	<b>63</b>	AO8	ADCINB11
GPIO56, SCIB_TX	DO17	<b>44</b>	<b>64</b>	AO9	ADCINA10/B1/C10
	DO18	<b>45</b>	<b>65</b>	AO10	ADCINA5
		<b>46</b>	<b>66</b>	AO11	ADCINA4/B8
		<b>47</b>	<b>67</b>	AO12	ADCINB4/C8
GPIO4, CANA_TX	DO19	<b>48</b>	<b>68</b>	AO13	ADCINB5
		<b>49</b>	<b>69</b>	AO14	ADCINA12/C5
		<b>50</b>	<b>70</b>	AO15	ADCINA0/B15/C15, DACA_OUT

**Table 3.10: LAUNCHXL-F280039C pin map for J1, J3, J5 and J7**

Function	RT Box			RT Box	Function
		<b>J4</b>	<b>J2</b>		
GPIO0, PWM1A	DI0	<b>40</b>	<b>20</b>	GND	
GPIO1, PWM1B	DI1	<b>39</b>	<b>19</b>	DI6	GPIO5, SPIA_STE, CANA_RX
GPIO2, PWM2A	DI2	<b>38</b>	<b>18</b>	DI7	GPIO32, BOOT2
GPIO3, PWM2B	DI3	<b>37</b>	<b>17</b>		
GPIO10, PWM6A	DI4	<b>36</b>	<b>16</b>	DO25	<b>RESET</b>
GPIO11, PWM6B	DI5	<b>35</b>	<b>15</b>	DI27	GPIO8, SPIA_SIMO
GPIO33	DO4	<b>34</b>	<b>14</b>	DO26	GPIO17, SPIA_SOMI
GPIO48	DO5	<b>33</b>	<b>13</b>	DO6	GPIO37
		<b>32</b>	<b>12</b>	DO7	GPIO22, LED5
		<b>31</b>	<b>11</b>	DO3	GPIO23
		<b>J8</b>	<b>J6</b>		
GPIO12, PWM7A	DI16	<b>80</b>	<b>60</b>	GND	
GPIO13, PWM7B	DI17	<b>79</b>	<b>59</b>	DI22	GPIO27, SPIB_STE
GPIO6, PWM4A	DI18	<b>78</b>	<b>58</b>	DI23	GPIO47
GPIO7, PWM4B	DI19	<b>77</b>	<b>57</b>		
GPIO16, PWM5A	DI20	<b>76</b>	<b>56</b>		
GPIO35, PWM5B	DI21	<b>75</b>	<b>55</b>	DO20	GPIO60, SPIB_SIMO
		<b>74</b>	<b>54</b>	DO21	GPIO61, SPIB_SOMI
		<b>73</b>	<b>53</b>	DO22	GPIO20, LED4
		<b>72</b>	<b>52</b>	DO23	GPIO26

<b>Function</b>	<b>RT Box</b>			<b>RT Box</b>	<b>Function</b>
		<b>71</b>	<b>51</b>	DO24	GPIO25

**Table 3.11: LAUNCHXL-F280039C pin map for J2, J4, J6 and J8**





plexim  
electrical engineering software

---